

KEY TO FIG 61

- | | | |
|-----------------------------|---|-----------------------------------|
| 1. Control Box. | 20. Fuel Indicator | 37. Instrument Illumination. |
| 2. Generator. | 21. Fuel Tank Unit. | 38. Steering Column Light Switch. |
| 3. Ignition Warning Lamp. | 22. Temperature Indicator. | 39. Line Fuse. |
| 4. Starter Motor. | 23. Temperature Transmitter. | 40. Main Beam Warning Lamp. |
| 5. Starter Solenoid. | 24. Flasher Unit. | 41. Headlamp Main Beams. |
| 6. Battery. | 25. Turn Signal Switch. | 42. Headlamp Dipped Beams. |
| 7. Ignition/Starter Switch. | 26. Turn Signal Lamps
Left Hand Side. | 43. Dip Switch. |
| 8. Horn Fuse. | 27. Turn Signal Lamps
Right Hand Side. | |
| 9. Horn Relay. | 28. Turn Signal Monitor. | |
| 10. Horn Push. | 29. Brake/Stop Lamp Switch. | |
| 11. Horns. | 30. Brake/Stop Lamps. | |
| 12. Oil Warning Lamp. | 31. Windscreen Wiper Motor. | |
| 13. Oil Pressure Switch. | 32. Wiper Motor Switch. | |
| 14. Fuse Unit. | 33. Front Parking Lamps. | |
| 15. Ignition Coil. | 34. Tail Lamps. | |
| 16. Distributor. | 35. Plate Illumination Lamp. | |
| * 17. Heater Blower Switch. | 36. Facia Lighting Switch. | |
| * 18. Heater Blower Motor. | | |
| 19. Voltage Stabilizer. | | |

CABLE COLOUR CODE

B Black.	U Blue.
G Green.	W White.
N Brown.	Y Yellow.
P Purple.	LG Light Green.
R Red.	

* SPECIAL ACCESSORY